

# 3D Printing of Multi-Material Hydrogels

IIB Project Final Presentation, Division C  
Nanoscience Centre, University of Cambridge

**Senior Supervisor:** Prof Shery Huang

**PhD Student Supervisor:** Yaqi Sheng

By **Lorcan Nicholls** ~ [ln356@cam.ac.uk](mailto:ln356@cam.ac.uk)

# Presentation Outline



Introduction



Theory



Materials and Methods



Results



Applications



Conclusions

# Introduction

---

What are multi-material hydrogels?



What has been done so far?

What is new about this work?

# Hydrogels

Crosslinked biopolymers swell in water to form a **solid structure**

We aim to make hydrogels that can **change their shape**. How might this be done?




**Problem:** relies on a **change in chemical environment**  
→ **totally unsuitable** for biomedical applications

Ionisation is pH dependent  
→ allows actuation

# Biocompatible Actuation of Hydrogels


True biocompatibility requires homeostasis

Integrate **hydrogels** with functional materials like **magnetic fibres**:



# 3D Printing of Magnetic Hydrogels

Implants that become part of a person's natural tissues over time



Shery's group has already built a 3D bioprinter (Printer.HM) for extruding soft materials in the Nanoscience centre. [1]

If we can similarly automate the production of magnetic fibres, we can **3D print the composite hydrogels.**

## Applications:

- 1) *In vitro* lung models
- 2) Smart biomedical textiles

# Theory

---


Structural Analysis  
Computational Modelling  
Material Selection



# Structural Analysis of Magnetic Fibre

Beam theory with a additional contact force from the hydrogel

Assume a clamped elastic beam surrounded by a soft hydrogel medium. The hydrogel exerts a viscoelastic reaction force on the displaced fibre [2]



$$EI \frac{\partial^4 y}{\partial x^4} + \rho \frac{\partial^2 y}{\partial t^2} =$$

Steady state

$$\underbrace{w(x)}_{\text{magnet force}} - \underbrace{ky(x, t)}_{\text{distributed reaction (Kelvin-Voigt model)}}$$

( $k$ : hydrogel stiffness per unit length,  $E$ : fibre modulus,  $I$ : fibre second moment of area)

Hydrogel force  $ky$  must not cause it to fail


Compliant hydrogels do not impede the motion



# Computational Modelling

Captures the nonlinear magnetomechanical coupling

**Solidworks:** simple structural FEA




Useful for checking **feasibility** of setup

But precise calculations are hard because **material properties are highly variable!**

**COMSOL:** complex multiphysics


fibre  
electromagnet



# Material Selection

Stiffness-limited design, with many secondary constraints

The relevant **failure criterion** for this application is **fatigue loading**



Material property chart, using **Ansys Granta L3** database

**Rule of thumb:** ensuring peak stress is **less than half of yield stress** will protect against high-cycle fatigue

# Materials and Methods

---

What materials were chosen?

How are the fibres made?

How are the composites made and tested?

# Fibre Compositions

Solvent + Polymer + Magnets




+



+



+



**DMF**  
(*N,N*-dimethylformamide)  
85% weight

**Acetone**  
(propanone)  
15% weight

Solvent

**Polystyrene**  
sets spinnability

Polymer Filler

**Iron oxide**  
sets magnetism

Magnets

**Magnetic solution**

Ready for  
nanospinning  
process



# Fibre Spinning

Using a robot arm, syringe and spinning frame




## Automated nanospinning

syringe full of fibre solution

robot arm

extruded fibres

spinning frame



diameter  $\sim 20 \mu\text{m}$

Produces this in about  
2 mins of spinning



# Hydrogel Compositions

## Gelatin/Alginate as a Self-Crosslinking UCST Hydrogel

Making gelatin hydrogels is **very simple**: just mix the powders together in water

**Printer.HM** (3D bioprinter) extrudes hot liquid phase hydrogel which **solidifies** on the stage as it cools below its **upper critical solution temperature (UCST)**

By **depositing the hydrogel onto the fibres**, the composite can be prepared as the hydrogel surrounds the fibres



# Testing the Magnetic Responsiveness

Use an electromagnet and measure the deflection



Electromagnet programmed to **switch on and off**

With a small contraction using the slider on the frame, the fibres will show **large deflections in the magnetic field**



# Results

---

Make Magnetic Polymer Solution  
Program Spinner  
Extrude Fibres  
Observe Under Microscope  
Assess Quality and Deformation

# Best Compositions for Magnetic Fibres

Need ~50% solid in fibre solution, with most compliant hydrogel

‘Best’ means 1) good spinnability, 2) homogeneous fibres, 3) high deflection

## Combinations of these variables were tested:

- Polystyrene mass fraction: {10%, 20%, 30%}
- Iron oxide mass fraction: {10%, 20%, 30%}
- Gelatin/Alginate (6:1) mass fraction: {7%, 2.33%, 0.33%}



**Best fibre solution:** using 20% polystyrene and 30% iron oxide

**Best hydrogel:** 2% gelatin and 0.33% sodium alginate in DI water

# Homogeneity of Fibre Dimensions

Over the range of tested compositions, size was quite consistent


Fibre Widths in Microscopy Images



More polymer/iron in the solution usually gives thicker fibres but correlation is weak

# Homogeneity of Fibre Dimensions

Over the range of tested compositions, size was quite consistent



Fibre length ~ 28 mm

Deflection ~ 1 mm

Strain ~ 5%

Reduced to **about half**  
when combined with  
the hydrogel

# Applications

---

*In vitro* lung model organoids  
Smart biomedical textiles

# Applications of Soft Actuators

Combines remote movement with biocompatibility

Can **combine with other projects** demonstrated from Shery's group (cryoprinting, fibre printing robot...) to **fully realise 3D printing capabilities**

## Application #1: Lung Organoids

Hydrogel loaded with cells could experience **actuation** to simulate lung tissue **breathing *in vitro***, study cell-matrix mechanobiological interactions

## Application #2: Smart Biomedical Textiles (+ Regenerative Medicine?)

Using bioresorbable hydrogels as post-surgical cavity fillers to **prevent internal adhesions** by moving into place, **reducing patient complications**

# Conclusions

---


Magnetic hydrogel composites can be  
3D printed in a modular fashion



# Key Takeaways from this Project


## Magnetic Hydrogels

- ★ It is easy to **functionalise** fibres with **magnetic materials**
- ★ The nanospinning process can be **automated** for **high-throughput** production
- ★ The fibres and hydrogels can be printed separately
- ★ Using (**30% iron oxide, 20% polystyrene**) fibres with (**2% gelatin, 0.33% alginate**) hydrogel was found to be optimal across a variety of metrics
- ★ The fibres are **resilient** and **do not delaminate or cut** the hydrogel during operation



# Thank You

## Q & A



---

### Sources cited in this presentation

- [1] Lei, I. M., Sheng, Y., Lei, C. L., Leow, C., & Huang, Y. Y. (2022). A hackable, multi-functional, and modular extrusion 3D printer for soft materials. *Scientific Reports*, 12(1). <https://doi.org/10.1038/s41598-022-16008-6>
- [2] Dillard, D. A., Mukherjee, B., Karnal, P., Batra, R. C., & Frechette, J. (2018). A review of Winkler's foundation and its profound influence on adhesion and soft matter applications. *Soft Matter*, 14(19), 3669–3683. <https://doi.org/10.1039/c7sm02062g>

**Own content:** photographs of experimental results not referenced